

Semi-Automatic EYELET MACHINE



DIGITAL STAR QATAR دیجیتال ستار قبطر

About us

Source of Digital Solutions...

Digital Star Qatar has been leading the digital scene in Doha for over 10 years, as suppliers and distributers of signage, advertising and LED solutions. Our commitment to providing the best quality machinery and top-notch technology from around the world has enabled us to set new and improved standards in sign and digital printing industries. DSQ has developed into a true trendsetter and a reliable destination for customers seeking exhaustive custom and wholesale solutions. From sign makers, digital print houses, POS/POP makers, retail fit-out companies, to exhibition stand builders, construction companies and glass and aluminum fabricators industries, we promise to take your business to unprecedented levels








Product **SPECIFICATION**

Inter Eyelet Size 12mm (Non-Replaceable Moult/ Mould/ Dies)

Weight 10kg

Application used to install grommet on the flex banner





Instruction Before using

- 1. Each machine has been tested before delivering, so just install the handle directly to use
- 2. Put eyelets into eyelet box, make sure not over lOOpcs and must use specified eyelets.
- 3. If no eyelets in guide rail, pull out the guide rail slightly by one hand, the other hand shake the handle at the same time, then to make eyelets fall down.
- 4. If you need to carry the machine, please carry the machine body. Don't take only the handle for avoiding injure.
- 5. If using other eyelets which are not specified eyelets, the loss all will be borne by customer

Trouble shooting

- 1. Problem: The eyelets can't come out from the eyelet box if eyelet box has enough eyelets.
 Solution: Check part2, take out sundries or deformation eyelets by using a small tool; If sundries too big to take out directly, then open eyelet box. If opening eyelet box and no sundries, check the brush whether have broken, If brush broken, then need to replace a new brush.
- 2. Problem: The eyelets can't align with the die when using.

 Solution: If eyelets can't be pressed on the cloth, release the screw and adjust partsl upward; If two eyelets pressed at one time, adjust partl downward. Tighten up the screw after adjusting.
- 3. Problem:Eyelets can't be pressed firmly or flex banners get stuck.

 Solution: adjust the stroke screw upward, or adust the stroke screw downward.



DIGITAL STAR QATAR دیجیتال ستار قطر

DOHA | QATAR | P O BOX: 47663



info@digitalstarq.com

+974 441 63 788

